


PART LIST

NO.	DESCRIPTION	Q'TY	NO.	DESCRIPTION	Q'TY
1.	HEADSTOCK	1	41.	HEX WRENCH	4
2.	FACEPLATE	1	42.	BOLT-A	1
3.	DRIVING CENTER	1	43.	CLAMP-A	1
4.	SPINDLE	1	44.	HEX NUT	3
5.	KEY	1	45.	ANGULAR SETTING ASSEMBLY	1
6.	BEARING	2	46.	SCREW	2
7.	"C" RING	2	47.	SPINDLE WRENCH	2
8.	SPRING	1	48.	GEAR ASSEMBLY	1
9.	BRACKET-SHIFING LEVER	1	49.	SPEED LABLE	1
10.	"C" RING	1	50.	INSTRUCTION MANUAL	1
11.	"C" RING	1	51.	HEX SCREW	3
12.	"C" RING	1	52.	RACK	1
13.	MOTOR	1	53.	BOLT-B	2
14.	KEY	1	54.	CLAMP-B	2
15.	SCREW	4	55.	ECCENTRIC ROD	1
16.	COVER-MOTOR	1	56.	TOOL REST BODY	1
17.	PULLEY-MOTOR (LEFT)	1	57.	HANDLE ASSEMBLY	2
18.	PULLEY-MOTOR (RIGHT)	1	58.	EXTENSION TOOL REST	1
19.	SPRING	1	59.	LOCK HANDLE TAIL STOCK	1
20.	SLEEVE	1	60.	TOOL REST	1
21.	"C" RING	2	61.	TAILSTOCK SPUR	1
22.	PUSH-OUT ROD	1	62.	TAIL SPINDLE	1
23.	HANDLE	2	63.	TAILSTOCK SCREW	1
24.	"C" RING	3	64.	HANDLE ASSEMBLY	1
25.	ECCENTRICITY ROD	1	65.	TAIL STOCK	1
26.	SCREW	1	66.	WASHER	1
27.	"C" RING	1	67.	HANDLE WHEEL	1
28.	PULLEY-SPINDLE (LEFT)	1	68.	SCREW	1
29.	V-BELT <i>Saeeco 2 625mm</i>	1	69.	SCREW	8
30.	PULLEY-SPINDLE (RIGHT)	1	70.	STAND UPPER COVER	2
31.	BEARING	1	71.	STAND LEG-I	2
32.	NUT-LOCK	1	72.	STAND LEG-II	2
33.	NUT	29	73.	TOOL TABLE	1
34.	CLAMP	2	74.	SWITCH <i>See PC130 Switch</i>	1
35.	NUT M4	2	75.	SWITCH BOX	1
36.	"C" RING	1	76.	POWER CORD	1
37.	TURNING BASE	1	77.	CARRIAGE BOLT STAND	20
38.	BED	1	78.	WASHER-STAND	20
39.	BAFFLE	2	79.	SPRING WASHER	8
40.	SCREW	4			



MC1100